

INSTALLATION GUIDANCE

EASY floor level shower tray In fiberglass, without drain, 80x80 cm

B&M SKU: ID15200 Idral code: 15200

Installation sequence

- 1 Connect the trap to the shower tray with the specified seals on both sides of the tray. Insert the 40 mm discharge pipe into the trap, following the manufacturer's arrangement.
- 2 Cover the supporting surface with a compact mortar bed, leaving space for the trap and discharge pipe.
- 3 Provide further fixing only at the external corners and check the tray is horizontal with a spirit level.
- 4 Connect the discharge pipe to the plumbing and check for leaks.
- 5 After positioning and fixing the tray, complete the surrounding floor covering.

Important

The wall and floor coverings must not bear on the tray edge. Idral specifies a 3-4 cm space between the tray edge and the wall/floor covering to allow for settlement. Seal joints with mildew-resistant silicone or elastic mortar. See Idral ISTA17-00.