

INSTALLATION GUIDANCE

Shower-Tray Waste Trap

B&M SKU: ID15600 Idral code: 15600

Installation sequence

- 1 Check the product, exact variant and all supplied components against the accompanying Idral technical drawing before installation.
- 2 Isolate the water supply and flush the pipework thoroughly to remove debris before making final connections.
- 3 Check that the shower tray outlet and downstream connection match the G1 1/2 and 40 mm connections shown in the technical sheet.
- 4 Fit the body, seals and retaining components in the correct order without overtightening the tray.
- 5 Connect the discharge pipe, fill the trap and perform a full leak and drainage test before closing access.

Important

Installation should be completed by competent personnel. The supplied Idral technical drawing, product-specific safety requirements and local water/electrical regulations remain authoritative.