

INSTALLATION INSTRUCTIONS

Sensor 6V Thermostatic Tap

Bridgepoint SKU: ID02511/PT Idral code: 02511/PT

1. GENERAL INFORMATION

- Installation must be carried out by professionally qualified personnel and the plumbing system must comply with current regulations.
- Flush supply pipework before installation. Use filtered water and provide accessible isolation valves for maintenance.

2. INSTALLATION

- Install the fitting on the basin/deck using the manufacturer fixing kit.
- Connect water hoses using the supplied filter seals; do not omit filters.
- Keep flexible hoses free from tension, traction and tight bends; maintain an accessible installation.
- Connect the battery power source only after plumbing connections have been checked.

3. COMMISSIONING

- Open the isolation valves and check all connections for leaks.
- Ensure the sensor window is clean and unobstructed, then connect power. Wait for the sensor start-up sequence to complete.
- Check sensor operation and confirm automatic shut-off. Detection distance can be adjusted where required according to the manufacturer instructions.